




ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV / SOURCE	 / SOURCE
-/-- / EXIT	-/--
	
	
	
VOL+	VOL+
VOL -	VOL -
P/CH+	P+
P/CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / SELECT	OK
P<P / SWAP	BACK
	SLEEP
TV / DTV	TV/DTV
INFO	INFO
 / GUIDE	EPG
RED / ▲	RED

[illegible]

COMPATIBLE DEVICES

Freedom

1 in 1 2 in 1 4 in 1

SUPERIOR
1 in 1 2 in 1 4 in 1

Simply
Digital (TV)

Simply⁺

Hotel TV

Safe



VISIT OUR
WEBSITE TO
DISCOVER